

MC987

TECHNICAL BULLETIN

EFF TREATMENT

EFF TREATMENT is an effective blended formulation which form a membrane and stop capillary action and build a protective surface.

It inhibits efflorescence on surfaces. Excellence result on beige and white calcium based stone

USES:

Recommended for use on:

- Marble
- Limestone
- Terrazzo
- Cementitious surface

COVERAGE:

Approximately 300 - 500 ft² (27 m² - 46 m²) per 946 ml

METHOD OF APPLICATION: SHAKE WELL

1. **Read entire label before using**
2. **TEST A SMALL AREA**, according to application instructions to determine desired results
3. Ensure surface is clean and dry
4. Apply EFF Treatment onto a manageable area of approximately 5 to 10 ft² (0.5 m² to 1 m²)
5. Using a synthetic fiber white pad, work the area in a side-to-side motion with a 175 to 300 RPM floor machine
6. Several treatments may be required to fully inhibit efflorescence
7. Allow area to dry 24 hours prior to sealing area
8. Repeat the process if higher gloss require, apply or spray CCV depending on surface traffic and consistency of routine maintenance program

MAINTENANCE:

- Apply Re-New as require for higher gloss result as needed depending on surface traffic and consistency of routine maintenance program
- On commercial entrance or high-traffic floors, daily buff is recommended as a routine protector



LIMITATIONS:

- Severely damaged by efflorescence may require professional attention. Total restoration, pitch hole refill with epoxy, re-grinding, honing and polishing
- Do not allow product to come in contact with any non-recommended surface

HANDLING AND STORAGE:

- Close container after each use
- Store in original container only
- Store between 40°F - 90°F (4°C - 32°C)
- Do not swallow and breathe gas/fumes/vapor/spray

CAUTION:

- **KEEP OUT OF REACH OF CHILDREN**
- Eye protection and rubber gloves should be worn during application
- **IF INGESTED:** Drink 1 to 2 glasses of water. Do not induce vomiting unless directed by medical personnel
- **IF INHALED:** Move to fresh air
- **EYE CONTACT:** Flush immediately with large amount of water for at least 15 minutes. Remove contact lenses if worn and seek immediate medical attention
- **SKIN CONTACT:** Flush immediately with large amount of water. Remove contaminated clothings