MC989 TECHNICAL BULLETIN

RE-NEW

RE-NEW is an effective formulation to improve surface hardness provides long term durability, less porous surface and stain resistance with natural glossy shine.

Excellence product for restorative works and on-going surface shine maintenance on cementitious surface, marble, limestone, terrazzo and natural stone

COVERAGE:

Approximately 300 - 500 ft² (27 m² - 46 m²) per 946 ml

METHOD OF APPLICATION: SHAKE WELL

- 1. Read entire label before using
- 2. **TEST A SMALL AREA**, according to application instructions to determine desired results
- 3. Ensure surface is clean, dry and free of existing coatings
- 4. Apply Re-New onto a manageable area of approximately 5 to 10 ft² (0.5 m² to 1 m²)
- 5. Buff area immediately for 1 to 2 minutes or until surface is dry with a white pad, beige pad using 175 to 300 RPM machine
- 6. For best result, machine should weigh 50 to 60 kgs
- 7. If a higher shine is desired, repeat the process till desire shine is achieve
- 8. When final procedure is complete, sweep or dust mop to ensure removal of any remnants
- 9. Re-apply as needed depending on volume of surface traffic and consistency of routine maintenance program

MAINTENANCE:

On commercial entrance or high-traffic floors, daily buff is recommended as a routine protector

LIMITATIONS:

- Severely damaged polished stone or stone installed with lippage may require Master Restoration System
 professional re-grinding, honing and polishing
- Do not allow product to come in contact with any non-recommended surface



HANDLING AND STORAGE:

- Close container after each use
- Store in original container only
- Store between 40°F 90°F (4°C 32°C)
- · Do not swallow and breathe gas/fumes/vapor/spray

CAUTION:

- KEEP OUT OF REACH OF CHILDREN
- Eye protection and rubber gloves should be worn during application
- IF INGESTED: Drink 1 to 2 glasses of water. Do not induce vomiting unless directed by medical personnel
- IF INHALED: Move to fresh air
- EYE CONTACT: Flush immediately with large amount of water for at least 15 minutes. Remove contact lenses if worn and seek immediate medical attention
- SKIN CONTACT: Flush immediately with large amount of water. Remove contaminated clothings



